

# COMPOSITES ADDITIVES AND ACCELERATORS

# **Additives for Composites**

# Wetting and Dispersing Additives

							Red	commended	d for			
Product Name	Composition	Active Content	Viscosity	Appearance			Unsatura	ed Polyest	er		Vinyl Esters/	Features & Benefits
					Gel coats	SMC/BMC	Pultrusion/ Filament Winding	Casting	Contact Molding/ Laminating	Putty	Epoxies	r catal co a belieft
Pat-Add DA 2250	Copolymer with acidic groups	100%	50-2000 ср	Clear to sl. hazy yellowish liquid								Wetting and dispersing agent commonly used for fillers, calcium carbonate, ATH, and inorganic pigments.
Pat-Add DA 2257	Solution of copolymer with acidic groups	52%	<150 cp	Clear yellowish liquid								Universal and cost-effective wetting and dispersing agent.
Pat-Add DA 2704	Unsaturated polyamides with acid polymers	52%	50-700 ср	Clear amber liquid								Wetting and dispersing agent commonly used for fillers and inorganic pigments. Reduces compound viscosity for higher filler loading. Used for UPR putties.
Pat-Add DA 2708	Unsaturated polyamides with acid polymers	80%	300-2000 ср	Clear amber liquid								Wetting and dispersing agent commonly used for fillers and inorganic pigments. Reduces compound viscosity for higher filler loading. Used for UPR putties.
Pat-Add DA 2709	Polyester	10%	<15 cp	Clear colorless to pale yellow liquid								Green chemistry. Wetting and dispersing agent that provides anti-settling properties even at low viscosity.
Pat-Add U 7510	Unsaturated carboxylic acid polymer with Polysiloxane copolymer	50%	250 ср	Clear amber colored liquid								Wetting and dispersing agent to prevent floatation and flooding. Improves gloss and surface smoothness.
Pat-Add DA 3225	HIA Polymeric - Solventfree	100%	Viscous flowable liquid	Yellowish colored clear to slightly hazy					For UPR pigment dispersions. Excellent pigment deflocculation, achieving high color strength.			

# Fiber Wetting Agent

								Rec	ommended	l for				
	Product Name	Composition	Active Content	Viscosity	Appearance			Unsaturat	ed Polyeste	er		Vinyl Esters/	Features & Benefits	
						Gel coats	SMC/BMC	Pultrusion/ Filament Winding	Casting	Contact Molding/ Laminating	Putty	Epoxies	roduros a ponento	
_	Pat-Add FW 1065	Polyether polysiloxane compound	51%	<50 cp	Clear pale – Yellow Liquid								Green chemistry. Effective wetting of multiple layers of reinforcements. Excellent compatibility with UPR, VE hybrids and most common hybrids.	

# Air Release Additives

						Recommended for										
Product Name	Composition	Active Content	Viscosity	Appearance			Unsaturate	l Polyester				Viny	/I Esters/Epo	oxies		
					Gel coats	SMC/BMC	Pultrusion	Casting	Laminating	Putty	Gel coats	Pultrusion	Casting	Laminating	Flooring/Lining	
Pat-Add AF 75	Organic polymer compound in hydrocarbon solvent	38%	<75 cp	Clear colorless liquid												
Pat-Add AF 76	Organic polymer compound in hydrocarbon and ester solvents		<25 cp	Clear colorless liquid												
Pat-Add AF 86	Organic polymer compound in hydrocarbon solvent	25%	<25 cp	Clear amber Liquid												
Pat-Add FL 12	Organic polymer compound in hydrocarbon solvent		<15 cp	Clear colorless liquid												

# Rheology Modifier

									Rec	commended t	for				
Product Name	Composition	Active Content	Viscosity	Appearance			Unsaturate	d Polyester				Viny	l Esters/Epo	xies	
					Gel coats	SMC/BMC	Pultrusion	Casting	Laminating	Putty	Gel coats	Pultrusion	Casting	Laminating	Flooring/Lining
Pat-Add Rheol 253	Organic polymer compound in hydrocarbon solvent	55%	<15000 cp	Clear amber liquid											

# **UPR Accelerators**

#### **PATcure**

Patcham offers a full range of metal based accelerators for the efficient curing of unsaturated polyester, vinyl ester and (meth)acrylate resins.

#### **General UPR Information**

Unsaturated Polyester Resins UPRs are the most commonly used thermoset resins in the world. It is one of the major composite materials used in automotive, marine and construction applications. It combines several advantages such as a light weight, high strength, corrosion resistance at relatively low cost.

#### **Accelerators**

Accelerators allow UPR to be cured relatively quickly at ambient temperatures. They can be incorporated into the resin monomer (pre-accelerated resin) or post-added before the addition of peroxide initiators (often called "catalysts").

#### PATcure Accelerators are available in various metal concentrations and carriers

Accelerators are mainly metal carboxylates of cobalt, potassium and copper.







Other metal carboxylates, zinc, sodium and calcium have niche applications.







#### Gel-time drift suppressors

Pre-accelerated resins are very practical because only one additional component, the peroxide catalyst, must be added to cure the resin at room temperature.

However, pre-promoted resins can be susceptible to a shelf life stability problem known as gel-time drift. Gel-time drift is defined as a change in the resin's measured gel time compared to the original gel time measured at the time of its manufacture.

PATcure Cobalt 21%	Neodecanoate
	High Flash Point 2-FHA free

#### **Economical Cobalt Alternative**

These products can be used in replace of cobalt accelerators.

PATcure 2720	Economical replacement for Cobalt 12%
PATcure 2721	Economical replacement for Cobalt 10%
PATcure 2722	Economical replacement for Cobalt 6%

#### **Colorless Cobalt**

These products provide similar gel and cure times to cobalt accelerators but without residual discoloration

PATcure 2725	Non Pinking Cobalt Equivalent to Cobalt 12%
PATcure 2716	Non Pinking Cobalt Equivalent to Cobalt 6%



**Cobalt Accelerators,** effectively, decompose organic peroxide initiators to form the free radicals that promote cross-linking of unsaturated resins. Cobalt may be used on its own or in conjunction with other metals listed below. Cobalt is typically used at 0.005 to 0.020% based on weight metal / binder solids.

Product	Solvent Medium
PATcure Cobalt Octoate 12%	White spirits
PATcure Cobalt Octoate 10%	White spirits
PATcure Cobalt Octoate 8%	White spirits
PATcure Cobalt Octoate 6%	White spirits
PATcure Cobalt Octoate 12% (Xylene)	Xylene
PATcure Cobalt Octoate 8%	Xylene
PATcure Cobalt Octoate 6%	Xylene
PATcure Cobalt Octoate 12% (D80)	High flash point. Aromatic free
PATcure Cobalt Octoate 10%	High flash point. Aromatic free
PATcure Cobalt Octoate 6%	High flash point. Aromatic free
PATcure Cobalt Neodecanoate 12% (D80)	High flash point. Aromatic free. 2-EHA free
PATcure Cobalt Neodecanoate 10%	High flash point. Aromatic free. 2-EHA free
PATcure Cobalt Neodecanoate 21%	High flash point. 2-EHA free
PATcure 2720	Low discoloration. Economic replacement for cobalt 12%
PATcure 2721	Low discoloration. Economic replacement for cobalt 10%
PATcure 2722	Low discoloration. Economic replacement for cobalt 6%
PATcure 2725	Non pinking cobalt. Equivalent to cobalt 12%
PATcure 2716	Non pinking cobalt. Equivalent to cobalt 6%

Do not premix cobalt accelerators with peroxides as it could cause an explosion hazard.





# **Potassium Accelerators** improve the efficacy of cobalt reducing discoloration. Assists in polymerization.

Product	Description
PATcure Potassium Octoate 15%	High flash point. Aromatic free
PATcure 2801	Water white 15% potassium. High flash point
PATcure Potassium Acetate 10%	High flash point. Aromatic free. 2-EHA free



## **Copper Accelerators** reduce the peak exotherm. Improve shelf life.

Product	Description
PATcure Copper Naphthenate 8%	2-EHA free
PATcure Copper Neodecanoate 10%	High flash point. 2-EHA free
PATcure Copper Neodecanoate 12%	High flash point. 2-EHA free. Economical



## **Zinc Accelerators** reduce the reaction rate allowing for clearer and more consistent polymers.

Product	Description
PATcure Zinc Naphthenate 8%	2-EHA free
PATcure Zinc Octoate 8% (D80)	High flash point
PATcure Zinc Octoate 16%	High flash point
PATcure Zinc Octoate 18%	High flash point
PATcure Zinc Octoate 23%	No VOC
PATcure Zinc Neodecanoate 19%	High flash point. No VOC. 2-EHA free



#### **Sodium Accelerators** produce slightly less discoloration than Potassium Accelerators.

Product	Description
PATcure Sodium Octoate 8%	High flash point



## **Calcium Accelerators** improve the action of cobalt and reduce gel-time drift in pigmented systems.

Product	Description
PATcure Calcium 10%	High flash point. 2-EHA free
PATcure Calcium Octoate 6% (N)	High flash point. Neutral





# PATCHAM (FZC)

P.O. Box: 7753, SAIF Zone, Sharjah, UAE

Tel.: +971 65570035 Fax: +971 65570038 Email: patcham@eim.ae



www.patchamltd.com

### **PATCHAM INDIA**

B-52, Pravasi Industrial Estate, Vishweshwar Nagar,

Off Aarey Road, Goregoan (E) Mumbai-400 063

Tel.: +91 96191 50550

## PATCHAM USA LLC

10 Commerce Road

Fairfield, New Jersey - 07004

Tel.: (201) 293 4282

Fax: (201) 820 0818

Email: officeadmin@patchamusa.com

## PATCHAM EUROPE BV

Dorpsstraat 24 A,

7451 BV Holten, Netherlands

Tel.: +31 630723609

Email: eu@patchamltd.com